



Water [Nuclease Free]

Nuclease-free water is essential in molecular biology because it is treated to remove enzymes called nucleases (DNases and RNases) that degrade DNA and RNA, which can ruin experiments.

| | |
|-------------------|-------------------------|
| Catalog No. | 150008 |
| Size | 500mL |
| Product Category | Stock Solution / Buffer |
| Storage/Stability | Ambient/2 year |
| Shipping | Ambient |

www.realgenelabs.com

For Research Use only